tp-link | tapo

Quick Start Guide

Smart Temperature and
Humidity Monitor

*Images may differ from actual products.
7106510140 REV1.1.0

Appearance

1 Vent Hole

2 Indicator Icons

3 Temperature*

4 Display/Reset
Button

5 Humidity*

*You can press the button to
switch display position.

Indicator Icons

⬚⬚ Connection
- Blinking: Connecting to hub
- Solid On: Connected to hub
- Off: No connection

▥ Battery Level
- ▱ Battery level < 20%
- ▭ Battery level < 5%

☺ Inside Comfort Level

☹ Outside Comfort Level

The default comfort level is temperatures between 20°C (68°F)
- 26°C (78.8°F) while humidity is between 30% - 60%.
You can customize the comfort level on the Tapo app.

Display/Reset Button

- **Single Press**
  Switch the temperature unit °C/°F.

- **Double Press**
  Switch the display position of temperature and
  humidity.

- **Press and hold for 5s**
  Reset your monitor to enter pairing mode.

⚠ Before You Start

A Tapo Hub is required. Make sure
your Tapo Hub is successfully added
via the Tapo app.

OR

1 Power Up Your Monitor

Remove the back panel and insert the
batteries. The screen will light up.

(Battery Type: AAA/LR03)

2 Set Up Your Monitor

Open the Tapo app and tap the ⊕ button. Select **Sensors** and then your model. Follow the app instructions to complete setup.

3 Test Your Monitor

Take the monitor to your preferred location. Make sure the Connection icon on the screen is solid on. If there is no connection icon, move it closer to your hub.

4 Place Your Monitor (The installation height should not be higher than 2 meters.)

Option 1:
Place it on a table or a shelf

OR

Option 2:
Attach the non-slip pad to the back and magnetically attach to metallic surfaces

OR

Option 3:
Stick to a clean wall with the included adhesive

3M

📞 For technical support, the user guide and more information, please visit **https://www.tapo.com/support/**