tapo

Quick Start Guide

Smart Water Leak Sensor

7106509948 REV1.0.0

Appearance

① Control Button
② LED
③ Sensor Probe
④ Buzzer

③ Sensor Probe
⑤ Battery Compartment

① **Control Button**

Single press
Silence alarm;
Test connection with the hub.

Double press
Adjust alarm volume. The volume level cycles through High, Normal, Low, and Mute.

Press and hold for 5s
Pair with hub.

② **LED Indicator**

| Blinking	Enter pairing mode
Blinks once	Adjusted alarm volume level to Mute
Blinks twice	Adjusted alarm volume level to Low
Blinks 3 times	Adjusted alarm volume level to Normal
Blinks 4 times	Adjusted alarm volume level to High

1 Power Up Your Sensor

Remove the battery insulation tab to power up your sensor. The LED should blink.

2 Check Your Sensor

The sensor will alarm if you drip water on the sensor probe or place it on a wet surface.

3 Set Up Your Sensor on the Tapo App

A Tapo Hub is required. Make sure your Tapo Hub's firmware is updated to the latest version and successfully set up via the Tapo app.

Open the Tapo app and tap the ⊕ button. Select **Sensors** and then your model. Follow the app instructions to complete setup.


Tapo App

4 Test Your Sensor

After setup, single press the control button on your sensor and check if the hub sounds an alarm.


5 Place Your Sensor

Lay the sensor flat to monitor water leaks.

How to Replace Battery

a. Remove the two screws securing the batteries and remove the back cover.

Two screws securing batteries

b. Replace with the new batteries (AAA/LR03).

?

Need some help?

Visit www.tapo.com/support/
for technical support, user guides, FAQs, warranty & more